

H5A-PTZ Camera

2 MP

The Avigilon H5A Pan-Tilt-Zoom (PTZ) camera brings wide area coverage, high-speed movement and long range detail, empowering security operators with 360° views to monitor large areas with ease, including greater zooming capabilities for evidentiary detail. This powerful camera delivers high-quality, detailed images with up to 36x zoom, which is ideal for critical infrastructure, public safety, sports and leisure, commercial buildings, transportation and large open areas (e.g. parking lots) for superior situational awareness.

As an Avigilon H5 platform camera, the H5A-PTZ camera is embedded with Next-Generation Video Analytics for enhanced object detection and classification, Unusual Activity Detection (UAD), Facial Recognition technology and Avigilon Appearance Search™ technology support to help ensure critical events do not go unnoticed.





Features



NEXT-GENERATION VIDEO ANALYTICS

Detects more objects with expanded object classifications and greater accuracy for faster responses, even in crowded scenes.



LONG RANGE DETAIL

2 MP with 36x zooming capabilities sets a new standard for high-performance 36x PTZ cameras with greater evidentiary detail.



H.264 AND H.265 WITH HDSM SMARTCODEC™ TECHNOLOGY

Optimizes compression levels for regions in a scene to help maximize bandwidth savings and keep internet connectivity costs down.



WATER, IMPACT AND ENCLOSURE RATED

IP66/7 rating for water resistance, IK10 impact rating for vandal resistance and NEMA 4X enclosure rating for windblown dust, water (e.g. rain, hose-directed water), and corrosion resistance.



LIGHTCATCHER™ TECHNOLOGY

Offers exceptional detail in areas with low lighting.



TRUE WIDE DYNAMIC RANGE

Captures details in scenes with both very bright and very dark areas.



ONVIF® COMPLIANT

Native ONVIF Profile S, T, and G compliance allows easy integration with existing ONVIF infrastructures.



FIPS 140-2 COMPLIANT

Enables the camera to be deployed at sites requiring FIPS-compliant cryptography.



EASY TRANSITION FROM H4 PTZ TO H5A-PTZ

Field-replaceable parts allow for an easy transition from H4 PTZ cameras to H5A-PTZ cameras.



WIDE AREA COVERAGE

Provides 360° zoomable views in high-resolution to monitor large areas with ease.

Specif	icatio	ons						
•			2.0 MP					
IMAGE	Image Sensor		1/2.8" progressive scan CMOS					
PERFORMANCE	Active Pixels	(H x V)	1920 (H) × 1080 (V)					
	Imaging Area	a (H x V)	4.8 mm × 2.7 mm; 0.189" × 0.106"					
	Minimum Illumination		0.1 lux (F/1.6) in color mode; 0.03 lux (F/1.6) in monochrome					
	Dynamic Rar	nge	120+ dB					
	Image Rate		Up to 60 fps					
	Aspect Ratio (Resolution		Down to (16:9) 384×216 or (5:4) 320×256					
	Scaling)							
	3D Noise Reduction Filter		Yes					
	Lens		4.3 mm to 129 mm, F/1.6 – F/4.7, autofocus					
LENS	Angle of Horizontal		63.7° – 1.9°					
	View	Vertical	38.5° – 1.1°					
	Zoom		36x (with image stabilization off), 30x (with imag	e stabilization on)				
IMAGE CONTROL	Video Compi	ression	H.264 HDSM SmartCodec, H.265 HDSM SmartCodec, Motion JPEG					
	Streaming Motion Data	ction	Multi-stream H.264, Multi-stream H.265, Motion J					
	Motion Dete		Pixel motion: Selectable sensitivity and threshold.	Classified object detection				
	Iris Control	nutter Control	Automatic, Manual (1/1 to 1/10,000 sec)					
		ontrol	Automatic, Open, Closed					
	Day/Night Co		Automatic, Manual					
			60 Hz, 50 Hz					
	White Balance Backlight Compensation		Automatic, Manual					
	_		On/Off					
	Privacy Zones Presets		3D, up to 64 zones					
	Presets Tours		500 named presets 10 named tours					
	Audio Compression							
	Method Digital Zoom	1	G.711, Opus Up to 100x when used with ACC™ Client					
			•					
	Electronic Image Stabilization Digital Defog		Adjustable/Off					
	19.1	,	Adjustable, on					
NETWORK	Network		100BASE-TX					
	Cabling Type		CAT5e					
	Connector		RJ-45					
	ONVIF		ONVIF compliance version 1.02, 2.00, Profile S, Profile T, Profile G (www.onfiv.org)					
	Security		Password protection, HTTPS encryption, digest authentication, WS authentication, user access log, 802.1x port based authentication, FIPS 140-2 L1					
	Protocol		IPv6, IPv4, HTTP, HTTPS, SOAP, DNS, NTP, RTSP, RTCP, RTP, TCP, UDP, IGMP, ICMP, DHCP, Zeroconf, ARP					
	Streaming Pi		RTP/UDP, RTP/UDP multicast, RTP/RTSP/TCP, RTP/RTSP/HTTP/TCP, RTP/RTSP/HTTPS/TCP, HTTP					
	Device Management Protocols		SNMP v2c, SNMP v3					
		_						
PERIPHERALS	Audio Input/Output		Line level input and output					
	External I/O Terminals		2 Alarm In, 2 Alarm Out					
	Onboard Storage		2 × microSD/microSDXC slot – minimum class 6; class 10/UHS-1 or better recommended.					
			IN-CEILING MOUNT	PENDANT MOUNT				
MECHANICAL	Dimensions (ø×H)		228 mm × 252 mm; 9.0" × 9.9"	242 mm × 347 mm; 9.5" × 13.7"				
	Weight		3.4 kg; 7.5 lbs	3.7 kg; 8.2 lbs				
	Dome Bubble		Polycarbonate					
	Body		Aluminum					
	Housing		Recessed mount	Pendant mount				
	Finish		Powder coat, grey					
	Tilt		-10° to 90°, e-Flip, 300°/second					
	Pan		360°, endless, 300°/second					
ELEOTE/	D			WO				
ELECTRICAL	Power Consumption		51 W max with 24 VDC aux power, 75 VA with 24 VAC aux power, 51 W max with 60 W PoE++, 25.5 W max with 30 W PoE+					
	Power Connector		24 VDC ±10%; 24 VAC rms ±10%, 50 or 60 Hz					
			60 W PoE: IEEE 802.3bt Class 6 PoE++, 60 W Cisco UPoE, Microsemi 60 W or higher midspans 30 W PoE: IEEE 802.3bt, 802.3at Class 4 PoE+					
			30 W PoE: IEEE 802.3bt, 802.3at Class 4 PoE+					

³V manganese lithium * 60W PoE may not be compatible with switches and injectors not listed here. Contact Avigilon sales or Avigilon technical support for more information.

Red and Black input wires

Power Connector


RTC Backup Battery


SUPPORTED VIDEO ANALYTICS EVENTS AT HOME POSITION Electromagnetic Immunity EN 55035, EN 61000-6-1, EN 50121-4 The event is triggered when the selected object type moves into the region of interest. Objects in Area Object Loitering The event is triggered when the selected object type stays within the region of interest for an extended amount of time.						
CERTIFICATIONS Certifications/Directives UL, CL, CE, ROHS, RCM Safety UL 62368-1, ISCA 62368-1, IEC/EN 62368-1 Environ- mental Pendant IEC 62262 IK10 Impact Rating, UL 2043 mental Pendant IEC 62262 IK10 Impact Rating, UL/CSA/IEC 60950-22, IEC 60529 IP66 and IP67 Weather Rating, NEMA 4X Electromagnetic Emissions Electromagnetic Immunity EN 55035, EN 61000-6-1, EN 50121-4 SUPPORTED VIDEO ANALYTICS EVENTS AT HOME POSITION Objects in Area Object Crossing Beam The event is triggered when the selected object type moves into the region of interest. Object Appears or Enters Area Object Appears or Enters Area Object Not Present in Area Object Stops in Area The event is triggered when no objects are present in the region of interest. Objects Leave Area The event is triggered when the specified number of objects have crossed the directional beam that is configured over the camera's field view. The event is triggered when no objects are present in the region of interest. Object Stops in Area The event is triggered when the specified number of objects have entered the region of interest. Objects Leave Area The event is triggered when the specified number of objects have entered the region of interest. Objects Leave Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when the specified number of objects have left the region of interest. Object Stops in Area The event is triggered when an object in a region of interest stops moving for the specified threshold time. Direction Violated The event is triggered when an object moves in the prohibited direction of travel.	οE					
CERTIFICATIONS Certifications/Directives Safety UL 62368.1, CSA 62368.1, IEC/EN 62368.1 Environ- mental Pendant EIC 62262 IK10 Impact Rating, UL 2043 Electromagnetic Emissions Electromagnetic Immunity EIC 62262 IK10 Impact Rating, UL/CSA/IEC 60950-22, IEC 60529 IP66 and IP67 Weather Rating, NEMA 4X Electromagnetic Immunity EN 55035, EN 61000-6-1, EN 50121-4 SUPPORTED VIDEO ANALYTICS EVENTS AT HOME POSITION Objects In Area Object Loitering The event is triggered when the selected object type moves into the region of interest. Object Scrossing Beam The event is triggered when the specified number of objects have crossed the directional beam that is configured over the camera's field view. The beam can be unidirectional or bidirectional. Object Appears or Enters Area Object Not Present in Area The event is triggered when no objects are present in the region of interest. Objects Leave Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when the specified number of objects have left the region of interest. Object Stops in Area The event is triggered when an object in a region of interest stops moving for the specified threshold time. Direction Violated The event is triggered when an object moves in the prohibited direction of travel.	-10 °C to +70 °C (14 °F to 158 °F)					
Safety UL 62368-1, CSA 62368-1, IEC/EN 62368-1 Environmental Pendant IEC 62262 IK10 Impact Rating, UL 2043 Pendant IEC 62262 IK10 Impact Rating, UL 2043 Electromagnetic Emissions FCC Part 15 Subpart B Class B, IC ICES-003 Class B, EN 55032 Class B, EN 61000-6-3, EN 61000-6-4, EN 61000-3-2, EN 61000-3-3, EN 5012 Electromagnetic Immunity EN 55035, EN 61000-6-1, EN 50121-4 SUPPORTED VIDEO ANALYTICS EVENTS AT HOME POSITION Object Sin Area The event is triggered when the selected object type moves into the region of interest. Object Loitering The event is triggered when the selected object type stays within the region of interest for an extended amount of time. Object Scrossing Beam The event is triggered when the specified number of objects have crossed the directional beam that is configured over the camera's field view. The beam can be unidirectional or bidirectional. Object Not Present in Area Object Not Present in Area The event is triggered when no objects are present in the region of interest. Object Stops in Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when the specified number of objects have left the region of interest. Object Stops in Area The event is triggered when an object in a region of interest stops moving for the specified threshold time. Direction Violated The event is triggered when an object moves in the prohibited direction of travel.						
Safety UL 62368-1, CSA 62368-1, IEC/EN 62368-1 Environmental Pendant IEC 62262 IK10 Impact Rating, UL 2043 Pendant IEC 62262 IK10 Impact Rating, UL 2043 Electromagnetic Emissions FCC Part 15 Subpart B Class B, IC ICES-003 Class B, EN 55032 Class B, EN 61000-6-3, EN 61000-6-4, EN 61000-3-2, EN 61000-3-3, EN 5012 Electromagnetic Immunity EN 55035, EN 61000-6-1, EN 50121-4 SUPPORTED VIDEO ANALYTICS EVENTS AT HOME POSITION Object Sin Area The event is triggered when the selected object type moves into the region of interest. Object Loitering The event is triggered when the selected object type stays within the region of interest for an extended amount of time. Object Scrossing Beam The event is triggered when the specified number of objects have crossed the directional beam that is configured over the camera's field view. The beam can be unidirectional or bidirectional. Object Not Present in Area Object Not Present in Area The event is triggered when no objects are present in the region of interest. Object Stops in Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when the specified number of objects have left the region of interest. Object Stops in Area The event is triggered when an object in a region of interest stops moving for the specified threshold time. Direction Violated The event is triggered when an object moves in the prohibited direction of travel.						
Environmental In-Ceiling Pendant IEC 62262 IK10 Impact Rating, UL 2043 IEC 62262 IK10 Impact Rating, UL/CSA/IEC 60950-22, IEC 60529 IP66 and IP67 Weather Rating, NEMA 4X Electromagnetic Emissions Electromagnetic Immunity EN 55035, EN 61000-6-1, EN 50121-4 SUPPORTED VIDEO ANALYTICS EVENTS AT HOME POSITION Objects in Area Object Loitering The event is triggered when the selected object type moves into the region of interest. Object Crossing Beam The event is triggered when the specified number of objects have crossed the directional beam that is configured over the camera's field view. The event is triggered by each object that enters the region of interest. This event can be used to count objects. Object Not Present in Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when the specified number of objects have left the region of interest. Object Stops in Area The event is triggered when an object in a region of interest stops moving for the specified threshold time. Direction Violated The event is triggered when an object moves in the prohibited direction of travel.	UL, cUL, CE, ROHS, RCM					
mental Pendant IEC 62262 IK10 Impact Rating, UL/CSA/IEC 60950-22, IEC 60529 IP66 and IP67 Weather Rating, NEMA 4X Electromagnetic Emissions FCC Part 15 Subpart B Class B, IC ICES-003 Class B, EN 55032 Class B, EN 61000-6-3, EN 61000-6-4, EN 61000-3-2, EN 61000-3-3, EN 5012 Electromagnetic Immunity EN 55035, EN 61000-6-1, EN 50121-4 SUPPORTED VIDEO ANALYTICS EVENTS AT HOME POSITION Object Loitering The event is triggered when the selected object type moves into the region of interest for an extended amount of time. Object Crossing Beam The event is triggered when the specified number of objects have crossed the directional beam that is configured over the camera's field view. The beam can be unidirectional or bidirectional. Object Appears or Enters Area The event is triggered when no objects are present in the region of interest. Object Set Enter Area The event is triggered when the specified number of objects have entered the region of interest. Objects Leave Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when an object in a region of interest stops moving for the specified threshold time. Direction Violated The event is triggered when an object moves in the prohibited direction of travel.	UL 62368-1, CSA 62368-1, IEC/EN 62368-1					
Electromagnetic Emissions Electromagnetic Emissions Electromagnetic Emissions Electromagnetic Emissions Electromagnetic Emissions Electromagnetic Immunity EN 55035, EN 61000-6-1, EN 5012-4 SUPPORTED VIDEO ANALYTICS EVENTS AT HOME POSITION Objects in Area The event is triggered when the selected object type moves into the region of interest. Object Crossing Beam The event is triggered when the selected object type stays within the region of interest for an extended amount of time. Object Scrossing Beam The event is triggered when the specified number of objects have crossed the directional beam that is configured over the camera's field view. The beam can be unidirectional or bidirectional. Object Appears or Enters Area Object Not Present in Area The event is triggered when no objects are present in the region of interest. Objects Leave Area Objects Leave Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when an object in a region of interest stops moving for the specified threshold time. Direction Violated The event is triggered when an object moves in the prohibited direction of travel.	IEC 62262 IK10 Impact Rating, UL 2043					
SUPPORTED VIDEO ANALYTICS EVENTS AT HOME POSITION Objects Crossing Beam The event is triggered when the selected object type moves into the region of interest for an extended amount of time. The event is triggered when the selected object type stays within the region of interest for an extended amount of time. Objects Crossing Beam The event is triggered when the specified number of objects have crossed the directional beam that is configured over the camera's field view. The beam can be unidirectional or bidirectional. Object Appears or Enters Area Object Not Present in Area The event is triggered when no objects are present in the region of interest. Objects Enter Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when an object in a region of interest stops moving for the specified threshold time. Direction Violated The event is triggered when an object moves in the prohibited direction of travel.	IEC 62262 IK10 Impact Rating, UL/CSA/IEC 60950-22, IEC 60529 IP66 and IP67 Weather Rating, NEMA 4X					
SUPPORTED VIDEO ANALYTICS EVENTS AT HOME POSITION Objects in Area The event is triggered when the selected object type moves into the region of interest. Object Loitering Objects Crossing Beam The event is triggered when the specified number of objects have crossed the directional beam that is configured over the camera's field view. The beam can be unidirectional or bidirectional. Object Appears or Enters Area Object Not Present in Area Objects Enter Area Objects Enter Area Objects Leave Area The event is triggered when the specified number of objects have entered the region of interest. Objects Leave Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when an object in a region of interest stops moving for the specified threshold time. Direction Violated The event is triggered when an object moves in the prohibited direction of travel.	FCC Part 15 Subpart B Class B, IC ICES-003 Class B, EN 55032 Class B, EN 61000-6-3, EN 61000-6-4, EN 61000-3-2, EN 61000-3-3, EN 50121-4					
Object Loitering Object Scrossing Beam The event is triggered when the selected object type stays within the region of interest for an extended amount of time. Objects Crossing Beam The event is triggered when the specified number of objects have crossed the directional beam that is configured over the camera's field view. The beam can be unidirectional or bidirectional. Object Appears or Enters Area Object Not Present in Area Object Not Present in Area The event is triggered when no objects are present in the region of interest. Objects Enter Area Objects Leave Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when an object in a region of interest stops moving for the specified threshold time. The event is triggered when an object moves in the prohibited direction of travel.	EN 55035, EN 61000-6-1, EN 50121-4					
Object Loitering Object Sorssing Beam The event is triggered when the selected object type stays within the region of interest for an extended amount of time. Objects Crossing Beam The event is triggered when the specified number of objects have crossed the directional beam that is configured over the camera's field view. The beam can be unidirectional or bidirectional. Object Appears or Enters Area Object Not Present in Area Object Not Present in Area Objects Enter Area The event is triggered when no objects are present in the region of interest. Objects Leave Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when an object in a region of interest stops moving for the specified threshold time. The event is triggered when an object moves in the prohibited direction of travel.						
Objects Crossing Beam The event is triggered when the selected object type stays within the region of interest for an extended amount of time. Objects Crossing Beam The event is triggered when the specified number of objects have crossed the directional beam that is configured over the camera's field view. The beam can be unidirectional or bidirectional. Object Appears or Enters Area Object Not Present in Area The event is triggered when no objects are present in the region of interest. Objects Enter Area Objects Leave Area The event is triggered when the specified number of objects have entered the region of interest. Object Stops in Area The event is triggered when an object in a region of interest stops moving for the specified threshold time. The event is triggered when an object moves in the prohibited direction of travel.	The event is triggered when the selected object type moves into the region of interest.					
The event is triggered when the specified number of objects have crossed the directional beam that is configured over the camera's field view. The beam can be unidirectional or bidirectional. Object Appears or Enters Area Object Not Present in Area Objects Enter Area Objects Leave Area The event is triggered when the specified number of objects have entered the region of interest. Objects Stops in Area The event is triggered when an object in a region of interest stops moving for the specified threshold time. The event is triggered when an object moves in the prohibited direction of travel.	The event is triggered when the selected object type stays within the region of interest for an extended amount of time.					
Object Not Present in Area Objects Enter Area Objects Leave Area The event is triggered when the specified number of objects have entered the region of interest. Objects Leave Area The event is triggered when the specified number of objects have left the region of interest. Object Stops in Area The event is triggered when an object in a region of interest stops moving for the specified threshold time. Direction Violated The event is triggered when an object moves in the prohibited direction of travel.						
Objects Enter Area The event is triggered when the specified number of objects have entered the region of interest. Objects Leave Area The event is triggered when the specified number of objects have left the region of interest. Object Stops in Area The event is triggered when an object in a region of interest stops moving for the specified threshold time. Direction Violated The event is triggered when an object moves in the prohibited direction of travel.	The event is triggered by each object that enters the region of interest. This event can be used to count objects.					
Objects Leave Area The event is triggered when the specified number of objects have left the region of interest. Object Stops in Area The event is triggered when an object in a region of interest stops moving for the specified threshold time. Direction Violated The event is triggered when an object moves in the prohibited direction of travel.	The event is triggered when no objects are present in the region of interest.					
Object Stops in Area The event is triggered when an object in a region of interest stops moving for the specified threshold time. Direction Violated The event is triggered when an object moves in the prohibited direction of travel.	The event is triggered when the specified number of objects have entered the region of interest.					
Direction Violated The event is triggered when an object moves in the prohibited direction of travel.	The event is triggered when the specified number of objects have left the region of interest.					
35	The event is triggered when an object in a region of interest stops moving for the specified threshold time.					
Tamper Detection The event is triggered when the scene unexpectedly changes.	The event is triggered when an object moves in the prohibited direction of travel.					
	The event is triggered when the scene unexpectedly changes.					
SUPPORTED Object Types in Outdoor CLASSIFIED Mode Vehicle, sub-types: Car, Truck, Bicycle, Motorcycle, Bus Person OBJECT TYPES ONLY TO A STATE OF THE PROPERTY						
Object Types in Indoor Mode Person	Person					
TEACH BY Teach By Example Yes, when used with Avigilon Control Center™ EXAMPLE						
AVIGILON CONTROL CENTER (ACC) VERSIONS (ACC) VERSIO	Appearance search when paired with appropriate server hardware.					
ACC Version 7.2 or higher FEATURES ACC Version 7.2 or higher FEATURES All supported analytic events with people and vehicles and all vehicle sub-types as classified objects. Appearance search when paired with appropriate server hardware. H.265 supported.	Appearance search when paired with appropriate server hardware.					

Outline Dimensions

In-Ceiling PTZ Dome Camera


(H5A-PTZ-DC)







Pendant PTZ Dome Camera


(H5A-PTZ-DP)





(H5A-PTZ-DP) WITH WALL ARM





Ordering Information

PTZ DOME CAMERAS	MP	WDR	LIGHTCATCHER TECHNOLOGY	ANALYTICS AT HOME POSITION	LENS	ZOOM	IP66/IP67	HDSM SMARTCODEC
2.0C-H5A-PTZ-DP36	2.0	True WDR	✓	✓	4.3 – 129 mm	36x*	✓	✓
2.0C-H5A-PTZ-DC36	2.0	True WDR	✓	✓	4.3 – 129 mm	36x*		✓

^{* 36}x zoom is achieved with Image Stabilization off. Image Stabilization set to on will provide 30x zoom.

PTZ CAMERA ACCESSORIES	PENDANT PTZ	IN-CEILING PTZ	DESCRIPTION
IRPTZ-MNT-NPTA1	✓		NPT Pendant Adapter
IRPTZ-MNT-WALL1	✓		Wall Arm Mount
H4-MT-POLE1	✓		Pole Mounting Bracket
H4-MT-CRNR1	✓		Corner Mounting Bracket
PTZMH-DC-CPNL1		✓	Metal Ceiling Panel for In-Ceiling Installation
PTZH5A-CLER1	✓	✓	Clear Bubble Assembly - Replacement
PTZH5A-SMOK1	✓	✓	Smoked Bubble Assembly - Replacement
POE-INJ-BT-60W-NA	✓	✓	Gigabit 802.3bt 60W PoE Injector, single port. NA/EU/AU options available.
POE-INJ2-PLUS-NA	√	✓	30W PoE+ Injector. Injector operational temperature range is -20°C (-4°F) to 40°C (104°F). NA/EU/UK/AU options available.
PTZ-ACCS-IC-RETRO		✓	H4 In-Ceiling PTZ audio retrofit kit
H5PTZ-ACCS-CABL1	✓		Cable gland nut kit, pack of 10